

## Slim Cool + Keyboard

The Slim Cool Plus is a waterproof and contaminant resistant keyboard with integrated two-button touchpad mouse. The two-button touchpad mouse is positioned below the space bar under the same silicon rubber housing. This 12-inch wide keyboard (without keypad) plus mouse saves valuable desk space. It uses only one USB cable for the keyboard and the integrated mouse. The sealed and rigid surface is ideal for industrial, marine, and medical use, as well as other applications where moisture, cleaning, and durability are a consideration. Because the Slim Cool Plus is also quieter than "standard" keyboards and mice, they are great for applications where noise generated from "key-clicks" and mouse button clicks are a problem.

### Weight:

825g (1.8 lb.)

### Dimensions:

296 mm x 212 mm x 15 mm  
(11.7" x 8.3" x 0.6")

### Cable length:

1.83 m (6')

### Storage temperature:

-20 °C - 70 °C  
-4 °F - 158 °F

### Operating temperature:

0 °C - 70 °C  
32 °F - 158 °F

### Voltage:

5 Volt

### Current input:

26 mA

### Composition:

100% Silicone Rubber  
PVC Cable  
100% Latex free

### System requirements:

USB interface

### Number of keys:

86 US Layout keys including  
Windows TM key, insert, delete,  
home, page up, page down, end and  
menu keys. This keyboard does not  
have a keypad.

### Warranty period:

Limited lifetime warranty

*Specifications subject to change  
without notice*

## Installing Your Slim Cool + Keyboard

**USB:** Attach the keyboard cable to a USB computer port. (You do not have to turn off your computer. There is no software to install.)

You can email us at: [info@ergonoflex.com](mailto:info@ergonoflex.com)

or call us at: (+32 2 538 33 38)

[www.ergonoflex.com](http://www.ergonoflex.com)



*ErgonoFlex*

## Cleaning Instructions for Waterproof Keyboards and Mice:

1. Clean the surface of the product by wiping, brushing, spraying or dipping it. Use only rags, sponges or soft bristle brushes.  
**DO NOT place the USB connector into the fluid.**
2. Either wipe with dry cloth or allow to air dry.

## Cleaning Instructions for Waterproof Keyboards while plugged in:

Lock the keyboard and the touchpad by pressing both Left and Right Control keys for about three seconds. After you finished cleaning press both Left and Right Control keys for 3 seconds to unlock the keyboard and the touchpad.

## Disinfectants recommended by Man & Machine, Inc.:

- Chlorine based (max 10% solution) - Chlorox, Novalsan, etc.
- Formaldehyde based - Formaldehyde Solution 37%, Vinco Formaldegen, etc.
- Glutaraldehyde based - Aldacide 200, Lysofume, Wavicide, etc.
- Phenol based - Lysol I.C., Beaucoup, Magna Clean, Tek-Trol, etc.
- Alcohol based - Cavicide, Isopropyl Alcohol, Medicide, etc.
- Oxidizing - Hydrogen Peroxide 3% Solution, Lifeguard Series, etc.
- Quaternary Ammonium - Roccal-D, Bacto-Sep, Parvosol, etc.
- Soap and water

## DO NOT USE:

- Petroleum based cleaning fluids, such as Gasoline
- Acetone
- Over 10% bleach solutions
- Temperature or pressure sterilization
- Buffing pads or scrubbing pads

THESE INSTRUCTIONS AND RECOMMENDATIONS HAVE BEEN PREPARED TO ADVISE THE PROPER METHODS FOR CLEANING YOUR PRODUCT.

ERGONOFLEX. OR THE LOCAL DISTRIBUTOR CANNOT ASSUME ANY RESPONSIBILITY FOR THE APPLICATION OF THEM. IF THERE ARE ANY QUESTIONS, PLEASE CONTACT PLACE OF PURCHASE OR ERG PRIOR TO CLEANING. ErgonoFlex 2008